

# Nanocomposites and nanomaterials

## Adsorption of Au<sup>3+</sup> ions from water solutions by SiO<sub>2</sub>/DMSA nanocomposites

**O.M. Kaminskiy<sup>1</sup>, N.V. Kusyak<sup>1</sup>, A.L. Petranovska<sup>2</sup>, S.P. Turanska<sup>2</sup>,  
P.P. Gorbyk<sup>2</sup>**

<sup>1</sup> Ivan Franko Zhytomyr State University,  
40 V.Berdychevska Str., Zhytomyr 10008, Ukraine, e-mail: [alexkamin@ukr.net](mailto:alexkamin@ukr.net),

<sup>2</sup> Chuiko Institute of Surface Chemistry, National Academy of Sciences of Ukraine,  
17 General Naumov Str., Kyiv 03164, Ukraine

As known, nanoscale pyrogenic silica (NPS) is widely used as an adsorbent for various applications. Properties of highly dispersive pyrogenic silica have been studied. Concentration of functional OH<sup>-</sup> groups for the studied SiO<sub>2</sub> was ~ 7-9.5 μmol/m<sup>2</sup> at S<sub>spec</sub> ~ 280 m<sup>2</sup>/g. Researches into morphology showed both non-porosity of primary particles and their tendency for clustering and agglomerations. DMSA attaches to silica via carboxyl group link with surface hydroxyl group according to the reaction:



The presence of DMSA and formation of coating on silica surface was proved by Fourier infrared spectroscopy investigations (Perkin Elmer 1720) in 400-4000 cm<sup>-1</sup> range and X-ray photoelectron spectroscopy method (EC-2402 with PHOIBOS-100-SPECS energy analyzer). The adsorption capacities (A<sub>max</sub>) of original and modified silica surfaces were determined with Au<sup>3+</sup> ions concentration measuring using atomic absorption analysis (C-115 M spectrophotometer, λ = 242.8 nm) in flame acetylene-air mixture. Au<sup>3+</sup> water solutions within 5-200 mg/L concentrations diapason were used for the studies.

The adsorption activities of nano-sized non-modified SiO<sub>2</sub> and SiO<sub>2</sub>/DMSA composite were investigated. Thus, for SiO<sub>2</sub> under 298 K, pH-3.0 A<sub>max</sub> = 10.6 mg/g and R value (the level of extraction) is 76.2 %, whereas for SiO<sub>2</sub>/DMSA nanocomposite in the same conditions A<sub>max</sub> = 21.8 mg/g and R = 85.7 %. The maximum Au<sup>3+</sup> extraction from water solutions takes place in the first 30-40 min and corresponds to the obtained kinetic data. The increase in Au<sup>3+</sup> ions equilibrium concentration leads to adsorbents surface monolayer adsorption saturation. This isotherm form can be described with Langmuir equation.

The obtained results open a prospect in SiO<sub>2</sub> and SiO<sub>2</sub>/DMSA composite use as magnetosensitive adsorbents for Au<sup>3+</sup> cations extraction from water solutions.